

MANUALE D'USO

■ TERMOMETRO DIGITALE DT 3

COD. 11132052



Funzioni:

- Misurazione della temperatura interna ed esterna.
- Rilevatore di umidità interna con indicatore del livello di comfort.
- Memoria di umidità e temperatura massima/minima

Parametri:

- Intervallo di misurazione della temperatura interna: da -30 a 50°C
- Intervallo di misurazione della temperatura esterna: da -50 a 70°C
- Intervallo di misurazione dell'umidità: da 20% RH a 99% RH).

Descrizione delle funzioni:

- Temperatura e umidità interna/esterna
- Premendo il bottone MAX il display visualizzerà la temperatura interna/esterna massima e l'umidità interna massima.
- Premendo il bottone MIN il display visualizzerà la temperatura interna/esterna minime e l'umidità esterna minima.
- Preme il bottone RESET per tornare alla temperatura reale e cancellare la la temperatura massima o minima in memoria.
- L'indicatore di comfort visualizzerà il livello ottimale di umidità ambientale.



Tecnosystemi S.p.A.

Via Mattei, 2/4 - Z. I. San Giacomo di Veglia
31029 Vittorio Veneto (Treviso)
Tel. / Phone +39 0438 500044 Fax +39 0438 501516
Email: info@tecnosystemi.com

www.tecnosystemi.com

OPERATING INSTRUCTIONS

■ DT – 3 DIGITAL THERMOMETER

COD. 11132052



FUNCTIONS:

- Measuring of internal and external temperature.
- Detecting internal humidity, with comfort level indicator.
- Memory for humidity and maximum/minimum temperature.

PARAMETERS:

- Internal temperature measuring range: -30 to 50°C
- External temperature measuring range: -50 to 70°C
- Humidity measuring range: 20% RH to 99% RH.

DESCRIPTION OF FUNCTIONS:

- Internal/external temperature and humidity
- Press the MAX button to display maximum internal/external temperature and maximum internal humidity.
- Press the MIN button to display minimum internal/external temperature and minimum external humidity.
- Press the RESET button to return to the actual temperature and erase the maximum or minimum temperature from the memory.
- The comfort indicator shows the level of ambient comfort.



Tecnosystemi S.p.A.

Via Mattei, 2/4 - Z. I. San Giacomo di Veglia
31029 Vittorio Veneto (Treviso)
Tel. / Phone +39 0438 500044 Fax +39 0438 501516
Email: info@tecnosystemi.com

www.tecnosystemi.com